



---

## Small Car

LF: 11(1) RF: 12 1/2 (2)

Left Steering: 7 3/4 (1) Right Steering: 14 (1)

Front Pannard: 11 (1) Rear Pannard: 14 7/8 (1)

LR: 10(2) RR: 23 3/4 (5/8) (2)

Complete Set: 1-7 3/4" 2-10" 2-11" 2-12 1/2" 1-14" 1-14 7/8" 2-23 3/4" (5/8)

W/Heims: Lefthand 3/8 x5/16 (2) Righthand 3/8x5/16 (2)

Lefthand 5/16 x5/16 (9) Righthand 5/16 x5/16 (9)

## Large and Medium Car

LF: 10.5(1) RF: 12 (2)

Left Steering: 7 3/4 (1) Right Steering: 14 (1)

Front Pannard: 11 (1) Rear Pannard: 14 7/8 (1)

LR: 10(2) RR: 23 3/4 (5/8) (2)

Complete Set: 1-7 3/4" 2-10" 1-10.5" 1-11" 2-12 " 1-14" 1-14 7/8" 2-23 3/4" (5/8)

W/Heims: Lefthand 3/8 x5/16 (2) Righthand 3/8x5/16 (2)

Lefthand 5/16 x5/16 (9) Righthand 5/16 x5/16 (9)

Older Cars May have LR set up. Top 9 3/4" (1) Bottom 8 1/2" (1)

Right Front Shock Support: 11" (1)



### Bull Rider Bolt Kit

16 - Trick Washers

25- 5/16-24 thin lock nuts

18-(5/16-24) 1" Bolts

4-(5/16-24) 1 1/4" Bolts

4-(5/16-24) 1 3/4" Bolts

3-(5/16-24) 2" Bolts

3-(5/16-24) 2 1/4" Bolts

2-(5/16-24) 1 1/2" Bolts

14- Black 8/32-1 Socket head nerf bolts

14- 8/32 lock nuts

5- 5/16 x 3/4 spacers